

PTZ Controller for Analog/ HD-AVS / IP PTZ



PTZ Controller Features:

- Controller for Analog and IP PTZ Cameras
- Controls ClearView DVRs, NVRs, and Video Servers
- RS485, RS422, USB, RS232, and Network Interfaces
- Three Dimensional Joystick Control of PTZ Functions
- Preset Position, Auto Scan, Auto Pan, Auto Tour and Pattern Control
- On-Screen Menu & User Operation Procedure Tips
- Connect to ClearView SmartPSS via USB

Access Anywhere

Android

iPhone

Most OS



7 YEAR WARRANTY

FREE LIFETIME SUPPORT

PTZ Controller

KB-KB-300